



8005 St-Michel, Mtl, H1Z3C9, 514-727-5899

Lundi-Vendredi: 8H-17H Samedi: 9H-13H

GARVIN LUMITRONIC NG

OPERATING INSTRUCTIONS

METER ON

When the taximeter is off, the displays will be off and the "LIBRE" indicator will be on. To turn on the taximeter, press on the switch "1" and the following will occur: The initial fare will appear in the fare display, the "OCCUPE" indicator will come on, the "LIBRE" indicator will turn off. You are ready for the trip



TIME OFF

To stop the waiting time, press the switch "2". The "DIST." indicator will light up and all time charges will stop. To resume waiting time charges, press the switch "2" again, the "DIST." indicator will go off and waiting time charges will be resumed.

METER OFF

To turn off your taximeter Garvin Lumitronic NG, it must be in "DIST." mode by pressing the switch "2", then press the switch "1", your taximeter will turn off and the "LIBRE" indicator will light up.

REVIEWING THE STATISTICS

The Garvin Lumitronic NG taximeter is equipped with six statistics, which can be viewed when the meter is in "LIBRE" mode. You can scroll through all the stats by repeatedly pressing switch "4".

DELETING THE STATISTICS

To delete all statistics, when the taximeter is in "LIBRE" mode, press the switch "4" five times and then press the switch "2". All the stats will be erased.

# Presses	DISPLAY	FNS #
One	Gross Dollars	1
Two	Extras	2
Three	Trips	3
Four	Paid distance	4
Five	Total distance	5
Six	Last gross dollars	6



COMMENCER UNE COURSE

Lorsque le taximètre est éteint, l'afficheur est éteint et l'indicateur « LIBRE » est allumé. Pour activer le taximètre Garvin Lumitronic NG, appuyez sur le bouton « 1 ». Le prix du départ sera affiché. L'indicateur « OCCUPÉ » sera allumé. L'indicateur « LIBRE » sera éteint. Vous êtes prêt pour la course.

ARRÊT DU TEMPS D'ATTENTE

Pour arrêter le temps d'attente, appuyez sur le bouton « 2 ». L'indicateur « DIST. » sera allumé et le taximètre ne calcule plus le temps d'attente. Pour réactiver le temps d'attente, appuyez encore sur le bouton « 2 ». L'indicateur « DIST. » sera éteint et le taximètre recommence à calculer le temps d'attente.



ÉTEINDRE LE TAXIMÈTRE

Pour éteindre le taximètre Garvin Lumitronic NG, il doit être en mode « DIST. » en appuyant le bouton « 2 ». Ensuite, appuyez le bouton « 1 », le taximètre s'éteint et l'indicateur « LIBRE » sera activé.

MÉMOIRES POUR LES STATISTIQUES

Le taximètre Garvin Lumitronic NG contient six blocs de mémoire. Vous pouvez traiter le contenu des blocs de mémoire lorsque le taximètre est en mode « LIBRE ». Appuyez le bouton « 4 », le taximètre Garvin Lumitronic NG affichera tous les blocs de mémoire.

SUPPRIMER LES MÉMOIRES POUR LES STATISTIQUES

Pour supprimer tous les mémoires pour les statistiques, lorsque le taximètre est en mode « LIBRE », appuyez le bouton « 4 » cinq fois et ensuite appuyez le bouton « 2 ». Tous les blocs de mémoire du taximètre sera supprimés.

# Appuis	AFFICHEUR	FNS #
Un	Recette totale	1
Deux	Total des suppléments	2
Trois	Nombres de courses	3
Quatre	Kilométrage payé	4
Cinq	Kilométrage total	5
Six	Dernière recette totale	6